

halo

TIRE INFLATOR

HOSE INSTALL TOOL
TK-100HI
USER MANUAL




HOSE INSTALL TOOL

USER MANUAL

CONTENTS

1x Hose install tool





DESCRIPTION

The tool included in this tool kit allows easy access to the valve stem connection and can be used to tighten and loosen the hose swivel at the valve stem. When installing the Halo please consult the installation instructions in the Halo User Manual (IN-100UM).

HOW TO USE

To engage the tool head with the swivel slide the tool past the swivel (A) and pull it back until the tool head engages with the hose swivel (B). Turn tool to tighten or loosen hose.




To prevent hose damage due to cross-threading during install, start by threading the hose onto the valve stem by hand.



Only tighten hose to finger tight plus 1/2 turn. Do not over-tighten hose. This may damage hose seal and cause a tire leak.



Leak check hose connection points with soapy water. Lightly pull on hoses to simulate forces experienced while driving and expose potential leaks. Failure to leak check may result in a flat tire.



For further assistance, contact technical support at 1 (650) 741-3231.